


MENU MAP

Click **Select** button to SAVE any input. Note: pressing and holding the Menu button momentarily will return you to the main screen from anywhere within the main menus (grayed screens).



ProtoThrottle™ Realistic Control Stand Throttle

